

ATI NC SERIES AMPLIFIERS RACKMOUNT KIT GUIDE

ATTACHING RACK EARS

1. Remove top cover using #2 Phillips head screwdriver.
2. Remove 8 screws that hold 4 small spacers on the sides of the amp. Save the spacers in case of conversion back to non-rack mount.
3. Attach rack pieces with the ears at the front of the amp facing outward. Use the same screws that were holding the spacers in place.
4. Replace the top cover, screw it securely in place.

ATTACHING RACK HANDLES

1. **WARNING:** removing both pairs of screws from the front panel will cause it to detach from the chassis. Attach only one handle at a time, removing only one pair of screws at a time.
2. Remove one pair of screws using the Allen wrench included in the rackmount kit.
3. Thread one pair of the longer screws (provided) through the holes in the handle.
4. Place the handle on front panel holes and tighten screws using the Allen wrench.
5. Repeat for second handle.