# SETUP GUIDE

1 GETTING STARTED WITH THE DEVICE P. 10

2 PRODUCT DESCRIPTION

LED AND BUTTONS P. 13

CONNECTORS P. 14


REMOTE P. 15

3 SAFETY WARNINGS P. 16


# 1 GETTING STARTED WITH THE DEVICE

**1/ Connecting your device**

Connect your speakers to the outputs indicated below, respecting the polarity.
Position the speakers an equal distance away from the listener for an optimal sound experience.




Following the instructions below the connectors, connect your chosen source.
Now connect your Devialet Astra to a mains power source using the power cord provided.




**2/ Turning on your device and installing the app**

Turn the device on by pressing the On/Off button on the side.



A **D** logo will appear for a few seconds on the device's screen, followed by a QR code.
Scan the code with your smartphone and follow the link that appears.

Download the Devialet app, then create a Devialet account or log in using your usual credentials.




Google Play is a trademark of Google LLC.

### 3/ Setting up your device with the Devialet app

To use your Devialet Astra, connect it to your network (Wi-Fi or Ethernet) by following the steps provided on the app. Make sure to position your device in an area with good Wi-Fi reception.

Once you've set up your device, the screen will default to the volume display.

### 4/ Using the remote

Make sure your Bluetooth remote is turned on (the power switch is located on the underside of the remote) and charged. To charge it, use the USB-C cable provided.

To pair your remote, press down on the speaker's Bluetooth button for 3 seconds to enable pairing mode, then hold down the remote's Previous and Next buttons simultaneously for 3 seconds until the pairing icon appears.

### 5/ Playing music

Access your source and discover how to use your different streaming services from the Devialet app.

You can also navigate between your active sources from your remote: hold down the Play/Pause button for 3 seconds to see the list of active sources and use the Previous/Next buttons to navigate between them, then press the Play/Pause button again to choose the source you want.


You can access the Advanced Configurator at any moment to delve deeper into your device's settings: configure Devialet Astra's inputs and outputs, SAM® and RAM® technology, etc.

To configure your device further, visit www.devialet.com/devialet-astra-configurator/.
Once saved to your Account, it will appear directly in your Devialet app.
You can then load it onto your Devialet Astra.

## DUAL-MONO AND OTHER SET UP

Dual-Mono configuration allows you to concentrate all of Devialet Astra's capabilities to one speaker and to radically enhance your system's performance.

This function requires you to connect to two amplifiers via the Devialet app.
Link them together using the two RCA connectors provided and connect each speaker to the corresponding amplifier as illustrated in the diagram below.




Other configurations are also possible. Contact our Customer Service team for more info.

# 2 PRODUCT DESCRIPTION

## LED AND BUTTONS




**LED device status**

- Flashing white: startup or update in progress
- Solid white: default
- Flashing blue: Bluetooth pairing in progress
- Solid blue: Bluetooth connected
- Flashing green: configuration via the Devialet app in progress
- Solid green: Awaiting configuration
- Flashing orange: failed connection between amplifiers
- Solid orange: network error
- Solid magenta: reset to factory settings




**On/Off button**
- Switch on or wake up the device
- Show device configuration
- Long press (2 seconds): switch off device
- Long press (7 seconds): reset to factory settings

**Bluetooth button**
- Switch to Bluetooth source
- Long press (2 seconds): enable Bluetooth pairing


## CONNECTORS

The connectors are configured by default and can be modified through the Advanced Configurator to better suit your preferences and to boost your system's performance.





**A** 


**PHONO (MM/MC) / LINE IN**
Advanced phono stage for turntable or line input for tuner

**B C** 


**PHONO (MM/MC) / LINE IN / DIGITAL IN**
Advanced phono stage for turntable or line input for tuner or digital S/PDIF (COAXIAL) input for CD, DVD, TV etc.

**D** 

**DIGITAL IN / LINE OUT**
Digital S/PDIF (COAXIAL) input for CD, DVD, TV etc.
or line output for subwoofer

**E** 

**DIGITAL IN / LINE OUT / DIGITAL OUT**
Digital S/PDIF (COAXIAL) input for CD, DVD, TV etc. or line output for subwoofer
or digital output for second amplifier

**F** 

**OPTICAL IN**
Optical input for CD player, computer, Blu-ray, router etc.

**G** 

**USB-C**
Input for computer, streaming device etc.

**H** 

**ETHERNET**
RJ45 input for network

**I J** 

**RIGHT SPEAKER & LEFT SPEAKER**
Universal speaker connectors (banana or fork) 4 mm

**K** 

**MAINS 100-240 V AC**
Mains power supply (grounding required)


**L** 

**EARTH FOR TURNTABLE TONEARM**

## REMOTE

The remote allows you to control the volume of your device, navigate your playlist and switch from one source to another.

You can turn the remote on and off using the switch located on the bottom. To recharge it, use the USB-C cable provided with the product with any standard plug.



**Ring**
- Volume control

**On/Off**
- Restart the device
- Long hold (2 seconds): Put the device on standby

**Play/Pause**
- Play or pause sound
- Mute or unmute
- Select your source in the Source menu
- Long hold (2 seconds): Access the Source menu

**Previous/Next**
- Fast-forward or rewind playlist
- Fast-forward or rewind podcast
- Navigate the Source menu
- Simultaneous long hold (2 seconds) Previous/Next: Switch to pairing mode (your speakers also need to be in pairing mode)

# 3 SAFETY WARNINGS

## UPDATES

All updates for the Devialet Astra are available through your Devialet app.
We strongly recommend that you install them to benefit from your device's latest optimizations.

## MAINTENANCE

Clean Devialet Astra and its remote using the microfiber cloth provided.
Clean the device when cold, without cleaning products. Do not use paper towels.


To allow heat to escape from your device, never cover it when it's in use.

## SUPPORT

For any questions regarding the use or maintenance of your device, do not hesitate to contact our online support. Devialet Help Center: help.devialet.com

For more information about Devialet Astra, visit devialet.com

## DIMENSIONS




Weight (without accessories): 7.2 kg